HAPPY HUMAN WARRANTY

SoundTools products are built to endure even the harshest live sound and audio environments. We are so confident in the reliability of our SoundTools products that every unit is covered by the Happy Human Warranty. If for any reason you're unhappy with any of your SoundTools products, simply return it to the place of purchase in its original packaging within one year for a full refund, no questions asked.

SoundTools road-tests all products for lifelong durability. If you experience any unhappiness after the one year warranty then we will happily replace your SoundTools product with a new or reconditioned unit, for life.

For warranty help, please contact your local dealer, email us at support@soundtools.com, or visit support.soundtools.com

THANK YOU!

We hope you enjoy your new SoundTools CAT Tails!

One of our main goals here at SoundTools is to create useful and quality tools for every SoundHuman's toolbox. If you ever have questions or want to share a cool way you've been using your SoundTools product, please reach out!

We'd love to see your product in action! Tag us and don't forget to #SoundTools

@RatSoundTools

SOUND TOOLS

CONTACT US

486 CONSTITUTION AVE
CAMARILLO, CA 93012

SUPPORT@SOUNDTOOLS.COM

(805) 383 -0777

SOUNDTOOLS.COM

CAT TAILS TRS STARTER GUIDE

Made For And By Sound Humans

CAT Tails TRS Starter Guide

Congratulations on your purchase of your new SoundTools CAT Tails. These CAT Tails will simplify your stage wiring system with its compact, reliable and disconnectable design. Here are some tips to get you started.

Step 1:
Use channels 1 thru 4 and connect your TRS jacks. The channel numbers are laser etched on the connector shells.

Step 2:
Insert a shielded CAT cable into the etherCON barrel, then connect the other end of your shielded cable to another CAT Tails, CAT Box, CAT Rack or other SoundTools Analog Audio Over CAT family product.



Breakout Tails
Each individual cable measures approximately 24" in length. CAT Tails breakouts are designed for high fidelity analog signal and conform with AES3 standards.



Signal Types
Each of the four TRS channels are isolated, meaning you can run different signal types simultaneously over the same CAT cable. The most common types of signal include analog audio, AES3, DMX and intercom. For mixed signals, a U/FTP or S/FTP cable is recommended.

SHIELD/GROUND
As with all quarter-inch connectors, the shield is connected to ground. Please note, the CAT Tails TRS use a common shield/ground for all four connectors, as is the norm.

The CAT Tails TRS are compatible with AES3, DMX, COM, and other 3-pin XLR based signals, and is AES72-2O compliant.